

Business Solutions

User Manual

ENS500-AC/ENS500EXT-AC/ ENS610EXT/ENS620EXT version 1.2

ErCorne

11AC Wave2 Outdoor Access Point / CPE

IMPORTANT

To install this Access Point please refer to the **Quick Installation Guide** included in the product packaging.

Table of Contents

Chapter 1 Product Overview	4
Introduction	. 5
Technical Specifications	. 8
Physical Interface	16
Chapter 2 Before You Begin	19
Computer Settings	20
Hardware Installation	24
Mounting the AP	25
Install Ground cable	28
Chapter 3 Configuring Your Access Point	29
Default Settings./Web Configuration	30
Chapter 4 Building a Wireless Network	31
Access Point Mode	32
Client Bridge Mode	33
WDS AP Mode	35
WDS Bridge Mode	36
WDS Station Mode	37
Chapter 5 Status	38
Overview	39
Connection	41
Realtime	41
Chapter 6 Network	43
Basic IPv4/IPv6 Settings	44
Spanning Tree Protocol Setting	44
Chapter 7 2.4 GHz/5 GHz Wireless	46
Wireless Settings	.47
2.4 GHz/5 GHz Wireless Network	48
2.4GHz/5 GHz SSID Profile	50

Wireless Security	51
Wireless MAC Filtering	54
Wireless Advanced	55
Fast Roaming	56
WDS Link Settings	57
Guest Network Settings	58
Chapter 8 Management	58
Management VLAN Settings	60
Advanced Settings	61
Time Zone	64
Auto Reboot Settings	65
Wi-Fi Scheduler	66
Tools	67
Account/Firmware	70
Backup/Restore	71
Log	73
Logout/Reset	74
Appendix	75
FCC Interference Statement	76
CE Interference Statement	77
Industry Canada Statement	.78
Professional Installation Instruction	80
Professional Installation Instruction (IC)	.81
Instructions d'installation professionnelle (IC)	.82
Detachabe Antenna Usage	83

Chapter 1 Product Overview



Introduction

Key Features - ENS620EXT

- Supports IEEE802.11ac wave2/ac/a/b/g/n wireless standards with up to 400 Mbps data rate on 2.4GHz band and 867Mbps on 5GHz band
- Support Wave 2 MU-MIMO function on 5GHz radio.
- Support Tx Beamforming to enlarge the transmitting distance.
- Perform 256-QAM to enhance air performance up to 400Mbps under the 2.4GHz radio
- Two detachable 5 dBi 2.4 GHz Omni-directional antennas
- Two detachable 5 dBi 5 GHz Omni-directional antennas
- Proprietary 24V Input design with Gigabits port supports.
- Flexible application by the built-in 2nd LAN port.
- More customized items on Band Steering for intellgent Management.
- Traffic Shaping to control bandwidth per SSID/user
- Secured Guest Network option available

The AP is 802.11 ac wave2/a/b/g/n Outdoor Access Point with speeds up to 400 Mbps on 2.4GHz and 867Mbps on 5GHz band. It can be configured as an Access Point, Client Bridge, or WDS (AP, Station & Bridge). The AP is an affordable solution which is built in high-powered radios and long-range settings to replace the ordinary Access Points that do not have the range and reach to connect to



a growing number of wireless users. With Wave2 features, the Access Point could reduce the handling period on client devices and network with more client devices at the same time. Meanwhile, the beamforming will gather energy to a specific direction and increase the transmitting distance.

Key Features - ENS610EXT

- Supports IEEE802.11ac wave2/ac/a/b/g/n wireless standards with up to 400 Mbps data rate on 2.4GHz band and 867Mbps on 5GHz band
- Support Wave 2 MU-MIMO function on 5GHz radio.
- Support Tx Beamforming to enlarge the transmitting distance.
- Perform 256-QAM to enhance air performance up to 400Mbps under the 2.4GHz radio
- Two detachable 5 dBi 2.4 GHz Omni-directional antennas
- Two detachable 5 dBi 5 GHz Omni-directional antennas
- Proprietary 24V Input design with Gigabits port supports.
- Flexible application by the built-in 2nd LAN port.
- More customized items on Band Steering for intellgent Management.
- Traffic Shaping to control bandwidth per SSID/user
- Secured Guest Network option available

The AP is 802.11 ac wave2/a/b/g/n Outdoor Access Point with speeds up to 400 Mbps on 2.4GHz and 867Mbps on 5GHz band. It can be configured as an Access Point, Client Bridge, or WDS (AP, Station & Bridge). The AP is an affordable solution which is built in high-powered radios and long-range settings to replace the ordinary Access Points that do not have the range and reach to connect to



a growing number of wireless users. With Wave2 features, the Access Point could reduce the handling period on client devices and network with more client devices at the same time. Meanwhile, the beamforming will gather energy to a specific direction and increase the transmitting distance.

Key Features - ENS500-AC/ENS500EXT-AC

- Supports IEEE802.11ac wave2/ac/n wireless standards with up to 867Mbps on 5GHz band
- ENS500EXT-AC ANT: Two detachable 5 dBi 5 GHz Omnidirectional antennas
- ENS500-AC ANT: 14dBi 5GHzdirectional antennas
- Support Wave 2 MU-MIMO function on 5GHz radio.
- Support Tx Beamforming to enlarge the transmitting distance.
- Proprietary 24V Input design with Gigabits port supports.
- Flexible application by the built-in 2nd LAN port.
- Traffic Shaping to control bandwidth per SSID/user
- Secured Guest Network option available



These AP are 802.11 ac wave2/ac/a/n Outdoor Access Point with speeds up to 867Mbps on 5GHz band. It can be configured as an Access Point, Client Bridge, or WDS (AP, Station & Bridge). The AP is an affordable solution which is built in high-powered radios and long-range settings to replace the ordinary Access Points that do not have the range and reach to connect to a growing number of wireless users. With Wave2 features, the Access Point could reduce the handling period on client devices and network with more client devices at the same time. Meanwhile, the beamforming features will gather energy to a specific direction and increase the transmitting distance.

Technical Specifications

ENS620EXT

Standard:

IEEE802.11 ac wave2/ac/a/n on 5 GHz IEEE802.11 b/g/n on 2.4 GHz

Antenna

2 x detachable 5 dBi 2.4 GHz Omni-directional Antennas 2 x detachable 5 dBi 5 GHz Omni-directional Antennas

Physical Interface

2 x 10/100/1000 Gigabit Ethernet Ports with PoE support LAN1 Port: Proprietary 24V Input LAN2 Port: Data Transmission

LED Indicator

Power LAN 1 LAN 2 2.4 GHz 5 GHz

Power Requirements

Proprietary 24V Power over Ethernet (PoE), Use included EPA2410GP only

Operation Modes

Access Point WDS Client Bridge

WDS Detail

WDS AP

WDS Bridge WDS Station

Management

Auto Channel Selection Multiple SSID: 16 SSIDs, 8 SSIDs per Radio BSSID SNMP V1/V2c/V3 MIB I/II, Private MIB VLAN Tag/VLAN Pass-through Clients Statistics Save Configuration as User Default Fast Roaming E-Mail Alert RADIUS Accounting Guest Network Traffic Shaping per SSID/user

Control

CLI Supported Distance Control (Ack Timeout) 802.1X Supplicant (CB Mode) Multicast Supported Auto Reboot Obey Regulatory Power

Security

WEP Encryption - 64/128/152 bit WPA/WPA2 Personal (WPA-PSK using TKIP or AES) WPA/WPA2 Enterprise (WPA-PSK using TKIP or AES) Hides SSID in beacons MAC address filtering, up to 32 MACs per SSID Wireless STA (Client) connection list Https Support SSH Support

QoS (Quality of Service) Complaint with IEEE 802.11e standard

Physical/Environment Conditions

Operating:

Temperature: -20 °C to 60 °C (-4 °F to 140 °F) Humidity (non-condensing): 90% or less

Storage:

Temperature: -30 °C to 80 °C (-22 °F to 176 °F) Humidity (non-condensing): 90% or less

ENS610EXT

Standard:

IEEE802.11 ac wave2/ac/a/n on 5 GHz IEEE802.11 b/g/n on 2.4 GHz

Antenna

2 x detachable 5 dBi 2.4 GHz Omni-directional Antennas 2 x detachable 5 dBi 5 GHz Omni-directional Antennas

Physical Interface

2 x 10/100/1000 Gigabit Ethernet Ports with PoE support LAN1 Port: Proprietary 24V Input LAN2 Port: Data Transmission

LED Indicator

Power LAN 1 LAN 2 2.4 GHz 5 GHz

Power Requirements

Proprietary 24V Power over Ethernet (PoE), Use included EPA2406GP only

Operation Modes

Access Point WDS Client Bridge

WDS Detail

WDS AP

WDS Bridge WDS Station

Management

Auto Channel Selection Multiple SSID: 16 SSIDs, 8 SSIDs per Radio BSSID SNMP V1/V2c/V3 MIB I/II, Private MIB VLAN Tag/VLAN Pass-through Clients Statistics Save Configuration as User Default Fast Roaming E-Mail Alert RADIUS Accounting Guest Network Traffic Shaping per SSID/user

Control

CLI Supported Distance Control (Ack Timeout) 802.1X Supplicant (CB Mode) Multicast Supported Auto Reboot Obey Regulatory Power

Security

WEP Encryption - 64/128/152 bit WPA/WPA2 Personal (WPA-PSK using TKIP or AES) WPA/WPA2 Enterprise (WPA-PSK using TKIP or AES) Hides SSID in beacons MAC address filtering, up to 32 MACs per SSID Wireless STA (Client) connection list Https Support SSH Support

QoS (Quality of Service) Complaint with IEEE 802.11e standard

Physical/Environment Conditions

Operating:

Temperature: -20 °C to 60 °C (-4 °F to 140 °F) Humidity (non-condensing): 90% or less

Storage:

Temperature: -30 °C to 80 °C (-22 °F to 176 °F) Humidity (non-condensing): 90% or less

ENS500-AC

Standard:

IEEE802.11 ac wave2/ac/a/n on 5 GHz

Antenna

Internal 14dBi high gain directional antenna

Physical Interface

2 x 10/100/1000 Gigabit Ethernet Ports with PoE support LAN1 Port: Proprietary 24V Input LAN2 Port: Data Transmission

LED Indicator

Power LAN 1 LAN 2 WLAN Weak Normal Strong

Power Requirements

Proprietary 24V Power over Ethernet (PoE), Use included EPA2406GP only

Operation Modes

Access Point WDS Client Bridge

WDS Detail

WDS AP WDS Bridge WDS Station

Management

Auto Channel Selection Multiple SSID: 8 SSIDs BSSID SNMP V1/V2c/V3 MIB I/II, Private MIB VLAN Tag/VLAN Pass-through Clients Statistics Save Configuration as User Default Traffic Shaping per SSID/user E-Mail Alert RADIUS Accounting Guest Network

Control

CLI Supported Distance Control (Ack Timeout) 802.1X Supplicant (CB Mode) Multicast Supported Auto Reboot Obey Regulatory Power

Security

WEP Encryption - 64/128/152 bit WPA/WPA2 Personal (WPA-PSK using TKIP or AES) WPA/WPA2 Enterprise (WPA-PSK using TKIP or AES) Hides SSID in beacons MAC address filtering, up to 32 MACs per SSID Wireless STA (Client) connection list Https Support SSH Support

QoS (Quality of Service) Complaint with IEEE 802.11e standard

Physical/Environment Conditions

Operating:

Temperature: -20 °C to 60 °C (-4 °F to 140 °F) Humidity (non-condensing): 90% or less

Storage:

Temperature: -30 °C to 80 °C (-22 °F to 176 °F) Humidity (non-condensing): 90% or less

ENS500EXT-AC

Standard:

IEEE802.11 ac wave2/ac/a/n on 5 GHz

Antenna

2 x detachable 5 dBi 5 GHz Omni-directional Antennas

Physical Interface

2 x 10/100/1000 Gigabit Ethernet Ports with PoE support LAN1 Port: Proprietary 24V Input LAN2 Port: Data Transmission

LED Indicator

Power LAN 1 LAN 2 WLAN Weak Normal

Strong

Power Requirements

Proprietary 24V Power over Ethernet (PoE), Use included EPA2406GP only

Operation Modes

Access Point WDS Client Bridge

WDS Detail

WDS AP WDS Bridge WDS Station

Management

Auto Channel Selection Multiple SSID: 8 SSIDs BSSID SNMP V1/V2c/V3 MIB I/II, Private MIB VLAN Tag/VLAN Pass-through Clients Statistics Save Configuration as User Default Traffic Shaping per SSID/user E-Mail Alert RADIUS Accounting Guest Network

Control

CLI Supported Distance Control (Ack Timeout) 802.1X Supplicant (CB Mode) Multicast Supported Auto Reboot Obey Regulatory Power

Security

WEP Encryption - 64/128/152 bit WPA/WPA2 Personal (WPA-PSK using TKIP or AES) WPA/WPA2 Enterprise (WPA-PSK using TKIP or AES) Hides SSID in beacons MAC address filtering, up to 32 MACs per SSID Wireless STA (Client) connection list Https Support SSH Support

QoS (Quality of Service) Complaint with IEEE 802.11e standard

Physical/Environment Conditions

Operating:

Temperature: -20 °C to 60 °C (-4 °F to 140 °F) Humidity (non-condensing): 90% or less

Storage:

Temperature: -30 °C to 80 °C (-22 °F to 176 °F) Humidity (non-condensing): 90% or less

Physical Interface (ENS620EXT)

Dimensions

Length: 191.6 mm (7.54") Width: 114.3 (4.49") Depth: 47.7mm (1.88")



- 1 2.4 GHz Antennas: Detachable 5 dBi 2.4 GHz Omni-directional
- 2 5 GHz Antennas Detachable 5 dBi 5 GHz Omni-directional
- 3 LAN Port 1 (Proprietary24V PoE): Ethernet port for RJ-45 cable.
- 4 LAN Port 2 : Ethernet port for RJ-45 cable.
- 5 **LED Indicators:** LED lights for Power, LAN Port 1, LAN Port 2, 2.4 GHz Connection and 5 GHz Connection.
- 6 Ground Cable
- 7 **Mounting Holes:** Using the provided hardware, the AP can be attached to a wall or pole.



Physical Interface (ENS610EXT)

Dimensions

Length: 186 mm (7.32") Width: 100 (3.94") Depth: 29mm (1.14")



- 1 2.4 GHz Antennas: Detachable 5 dBi 2.4 GHz Omni-directional
- 2 5 GHz Antennas Detachable 5 dBi 5 GHz Omni-directional
- 3 LAN Port 1 (Proprietary24V PoE): Ethernet port for RJ-45 cable.
- 4 LAN Port 2 : Ethernet port for RJ-45 cable.
- 5 **LED Indicators:** LED lights for Power, LAN Port 1, LAN Port 2, 2.4 GHz Connection and 5 GHz Connection.
- 6 **Mounting Holes:** Using the provided hardware, the AP can be attached to a wall or pole.



Physical Interface - ENS500-AC/ENS500EXT-AC

Dimensions

Length: 186 mm (7.32") Width: 100 (3.94") Depth: 29mm (1.14")

- 1 **5 GHz Antennas** Detachable 5 dBi 5 GHz Omni-directional Antennas (ENS500EXT-AC Only)
- 2 LAN Port 1 (Proprietary24V PoE): Ethernet port for RJ-45 cable.
- 3 LAN Port 2 : Ethernet port for RJ-45 cable.
- 4 **LED Indicators:** LED lights for Power, LAN Port 1, LAN Port 2, 2.4 GHz Connection and 5 GHz Connection.
- 5 **Mounting Holes:** Using the provided hardware, the AP can be attached to a wall or pole.



Chapter 2 Before You Begin



Computer Settings

Windows XP/Windows 7/Windows 8/Windows 10

In order to use the Access Point, you must first configure the TCP/IPv4 connection of your Windows OS computer system.

1a. Click the Start button and open the Control Panel



Windows XP

Windows 7

1b. Move your mouse to the lower right hot corner to display the Charms Bar and select the **Control Panel** in Windows 8 OS.



Windows 8

1c. In Windows 10, click Start to select All APPs to enter the folder of Windows system for selecting Control Panel.



Windows 10

2a.In Windows XP, click Network Connections.



2b.In Windows 7/Windows 8/Windows 10, click View Network Status and Tasks in the Network and Internet section, then select Change adapter settings.



3. Right click on Local Area Connection and select Properties.



4. Select Internet Protocol Version 4 (TCP/IPv4) and then select Properties.

etworking Shaon	9	
Connect Lang		
🔮 Intel(R) 8253	78DC Gigabě Network Co	nection
The connection us	es the following items	Configure
Hite and P Hitemet P	ninter Sharing for Microsof totopol Version 5 (TCP/IP Topology Discovery Map r Topology Discovery Her	t Networks VG oper I/O Driver iponder
	1 Saved	Properties
instal		

5. Select **Use the following IP address** and enter an IP address that is different from the Access Point and Subnet mask, then click **OK**.

Note: Ensure that the IP address and Subnet mask are on the same subnet as the device.

For example: ENH220EXT IP address: 192.168.1.1

PCIP address: 192.168.1.2 - 192.168.1.255

PC Subnet mask: 255.255.255.0

eneral	
rou can get IP settings assign the capability. Otherwise, you for the appropriate IP setting	ed autonatically if your network supports i need to ask your network administrator i.
Obtain an IP address au gr the following IP add	ionatically ess:
(P address;	192 , 168 , 1 , 20
Subriet mask:	255 . 255 . 255 . 0
Default gateway:	and the second
Optam ONS server addre	an a toward a
Use the following DNS set	rver øddresset:
Preferred DNS server:	1 4 4
Alternate DNS server:	4 1 4
Vajdate settings upon e	wit Advanced

Apple Mac OS X

- **1.** Go to **System Preferences** (Which can be opened in the Applications folder or selecting it in the Apple Menu).
- 2. Select Network in the Internet & Network section.



3. Highlight **Ethernet**.

- 4. In Configure IPv4, select Manually.
- **5.** Enter an IP address that is different from the Access Point and Subnet mask then press **OK**.

Note: Ensure that the IP address and Subnet mask are on the same subnet as the device.

For example: A device IP address: 192.168.1.1

PCIP address: 192.168.1.2 - 192.168.1.255

PC Subnet mask: 255.255.255.0

6. Click Apply when done.



Hardware Installation

- A. Remove the rear bottom panel.
- **B.** Connect one end of the Ethernet cable into the LAN(PoE) port of the AP/Bridge and the other end to the PE port on the PoE Adapter.
- **C.** Connect the Power cord with the PoE Adapter and plug the other end into an electrical outlet.
- D. Connect the second Ethernet cable into the LAN port of the PoE adapter and the other end to the Ethernet port on the computer.

E.Place the pane removed from step A back into the device.

F.Screw on the provided antennas to the top of this device. (Applied on the ENS500EXT-AC / ENS620EXT)

This diagram depicts the hardware configuration.



Note: The Access Point **NOLY** supports the included proprietary 24V PoE adapter.

Note2: The Galvanic isolator needs to be installed between the power supply and the product.

Mounting the AP

Using the provided hardware, the AP can be attached to a wall or a pole.

1. Wall Mounting Kit (Anchors: Φ 5.5*18 mm & Bolts: Φ 8*25mm)



2. Pole Mounting Strap $(\Phi 63.5*12.7 \text{ mm})$



To attach the AP to a wall using wall mounting kit.

- Determine where the Access Point to be placed and mark locations on a surface for the two mounting holes. Use an appropriate drill bit to drill two 8.1mm diagram and 26mm depth holes in the markings and hammer the bolts into the opening.
- **2.** Screw the anchors unto the holes until they are flush with the wall.

- **3.** Screw the included screws into the anchors.
- **4.** Place this Access Point against wall with the mounting heads.



To attach the AP to a pole using the provided pole mounting kit:

1. Thread the open end of the pole strap through the two tabs on the Pole Mount Bracket.

2. Lock and tighten pole strap to secure pole mount bracket to the pole.





Install Ground cable (ENS620EXT Only)

No outdoor APs are built to withstand a direct lightning strike. To prevent a directly ligtning stirke into outdoor APs, they should be properly grounded to a viable path for lightning surge to deliver to ground so that is does not go into the building network. This AP have a ground lug on the left side of this AP which is applied to attach a proper ground to.

*Attention: You must always install an external grounding wire ensure that you have completed grounding before you connect power to the unit.





Chapter 3 Configuring Your Access Point



Configuring Your Access Point

This section will show you how to configure the device using the web-based configuration interface.

Default Settings

Please use your Ethernet port or wireless network adapter to connect the Access Point.

IP Address 192.168.1.1 Username / Password admin / admin

Web Configuration

1. Open a web browser (Internet Explorer/Firefox/Safari/ Chrome) and enter the IP Address http://192.168.1.1



Note: If you have changed the default LAN IP Address of the Access Point, ensure you enter the correct IP Address.

2. The default username and password are admin. Once you have entered the correct username and password, click the Login button to open the web-base configuration page.



- * The model name will be varied by different models.
- **3.** If successful, you will be logged in and see the User Menu of this Access Point.

Chapter 4 Building a Wireless Network



Before starting to configure this Access Point, you may realize the used scenario under varied operating modes. The AP has the ability to operate in various modes. This chapter describes purpose of different operating modes and lists down the operating modes for outdoor Access Points or Client Premise Equipments (CPE).

Access Point Mode

In Access Point Mode, AP behaves likes a central connection for stations or clients that support IEEE 802.11ac/a/b/g/n networks. The stations and clients must be configured to use the same SSID (Service Set Identifier) and security password to associate with the AP. The AP supports up to eight SSIDs per band at the same time for secure access.



Client Bridge Mode

The Access Point essentially acts as a wireless adapter that connects to an access point to allow a system of wireless access to the network in the Client Bridge mode. Since the computers are on the same subnet, the Access Point can broadcast to reach all end-devices.

If you use the client bridge mode in this Access Point, you can use the AP Detection feature to scan for Access Points within range. When you find an Access Point, configure this Access Point to use the same SSID and Security Password as the Access Point to associate with it.



The AP can be used as a centralized Outdoor Access Point with which other EnGenius Wireless 802.11b/g/n 2.4 or ac/a/n 5 GHz Outdoor Client Bridges can associate; leveraging the long-range capability of their internal high-gain directional antennas, resulting in a very cost-effective solution to expand a company network over a multiple building campus.



WDS AP Mode

The AP also supports WDS AP mode. This operating mode allows wireless stations to connect with Access Point via using WDS technology. In this mode, configure the MAC addresses or SSIDs in both Access Points to enlarge the wireless area by enabling WDS Link settings. WDS AP mode supports up to four (4) AP MAC addresses and four (4) SSIDs at the same time.



WDS Bridge Mode

In WDS Bridge Mode, the Accesss Point can wirelessly connect different LANs by configuring the MAC address and security settings of each Access Points. Use this operating mode when two wired LANs located a small distance apart want to communicate with each other. The best solution is to use the Access Point to wirelessly connect two wired LANs, as shown in the following diagram.

WDS Bridge Mode can establish up to four (4) to eight (8) WDS links, creating a star-like network.

Note: WDS Bridge Mode does not act as an Access Point. Access Points linked by WDS are using the same frequency channel. More Access Points connected together may lower throughput. This configuration can be susceptible to generate endless network loops in your network, so it is recommended to enable the Spanning Tree function to prevent this from happening.


WDS Station Mode

WDS station (WDS STA) mode expands the WDS by receiving a wireless signal/service and sharing it through the Ethernet port. With WDS STA mode,



Chapter 5 **Status**



Overview

Save Changes

This page lets you save and apply the settings shown under **Unsaved changes list**, or Revert the unsaved changes and revert to the previous settings that were in effect.



Device Status

Clicking the **Device Status** link under the **Overview** menu shows the status information about the current operating mode.

 The **Device Information** section shows general system information such as Device Name, MAC Address, Current Time, Firmware Version, and Management VLAN ID

Note: VLAN ID is only applicable in Access Point, WDS AP or WDS BR mode.

Device Information		
Device Name	ENS620EXT	
MAC Address		
- LANS	68-DC-96-00-06-10	
- 1.4N2	88-DC:96:00:0011	
- Winitets LAN - 1.4GHz	68 DC:94:00:00:12	
- Winstewa LAM - SIGHz	85-DC-96-00:00-13	
Country	USA	
Current Local Time	Toe &/ 12 11:45:00 2016	
Uprimie	Dh 4m 57s	
Firmulare Version	1.0.6	
Management VLAN ID	Untopoid	

 The Memory Information section shows usage of memory such as Total Available, Free, Cached, Buffered

Memory Information			
Totsi Aveilable	((among all) (10/21) 43 (10/27)		
Free	management (2 minute on parent)		
Cached	[T0704] 44 (2012) 48 (2016] 1		
Buffered	E- Brit & Sec 2 (2) (2) (2) (4) (2) (4)		

 The LAN Information section shows the Local Area Network settings such as the LAN IP Address, Subnet mask, Primary DNS Address, Secondary DNS Address, status of DHCP client, and status of Spanning Tree protocol (STP).

LAN Information - IPv4

JP Address	192.168 1.1	
Subrit Mesk	255.255.255.0	
Gabeway	192,169 1,1	
Primary DNS	0.0.0.0	
Secondary DNS	0.0.0.0	
DHCP Client	Deathin	
Spanning Tree Protocol(STP70	Disable	

The Wireless LAN Information 2.4 GHz/5 GHz section shows wireless information such as Operation Mode, Frequency, and Channel. Since this Access Point supports multiple-SSIDs, information about each SSID, the ESSID, and security settings, are displayed

Note: Profile Settings are only applicable in Access Point and WDS AP modes.

Wireless LAN Information - 2.4GHz

Operation	Mode	Access Point		
Wreless t	Mode	\$02.11 B/G/N		
Channel f	Mandwighth	20.9942		
Channel		2.412 GHz(Channel 1)		
Profile	160	Security	100	807.10
21	ExCentus, Text	TURE	1	(Interest
12	triGentus-nac _1-2.4Ghz	April	1	Disable
18.	SiGenia macci - 2.40%	fame	1	DADY
34	E-Gentle-Hart, 4-2,4GH	- Appoint		trania.
14	ErGermeiman, 1-J.HDre	1079		Dates.
++	Reflection many 18-2 white	fpane.		Damia
47	Informational France	lane	- E	Datie
16	Difference mator, Ariz Albert	Assessed.		Disable
18.	Indenut-1 Adds: Guestiensum	tang		Depter

Wireless LAN Information - 5GHz

Operation Mode	WDS Access Point		
Wireless Mode	802.11 N/AC		
Channel Bandwisth	SO MH2		
Channel	5 180 GHz(Chanse) 38)		
ingine sittl	Security	VE	192.00
F1 EnGenue Test	Nerva.	. 11	District
42 EnDeniue mac. 2-5696	10rw	52	Date
13. Etiliania mar. 3.5040	ligna	3.2	Inste
14 EnGence-Instr4/SQND	19008	34	Dillor
(12) Providence Street a		39.10	

• The **Statistics** section shows Mac information such as SSID, MAC address, RX and TX.

Statistics				
SSID	MAC	RX(Packets)	TX(Packets	
Bilariat	88-242-96-00100	154.37 KB(#29 Pets.)	#81.75 (#(85? Pole.)	
Interior man 3-Littlet	Address: 444,000-009-12	D JOG W/D PBML	CO. RI KATLAR PLM.	
provingence, provid	00101-96-98-98-98-11	0.00 2(0.965.)	ALCO RE(44 PSts.)	

Connections

2.4 GHz/5 GHz Connection List

Click the connection link under the Overview menu displays the connection list of clients associated to the AP's 2.4 GHz/5 GHz, along with the MAC addresses and signal strength for each client. Clicking **Refresh** updates the client list.

Note: Only applicable in Access Point and WDS AP modes.

2.4 GHz/5 GHz WDS Link List

Click the connection link under the Overview menu. This page displays the current status of the WDS link, including WDS Link ID, MAC Address, Link Status and RSSI.

Note: Only applicable in WDS AP and WDS Bridge modes.

	and some	14	RX	8551	Block
/DS Link List - 5	GHz				
WDS LINE ID #	HAC Address		(ink Status		RSSI(dBm)

Realtime

Realtime

The Realtime section contains the following options:

CPU Loading: 3 minutes CPU loading percentage information, it displays current loading, average loading and peak loading status. Left bar is loading percentage; button is time tracing. Interval is every 3 seconds



Traffic Loading: 2.4GHz and 5GHz and Ethernet port inbound and outbound traffic by current, average and peak time.



Realtime Connection (Pkts): Overview on current active network connections. It displays UDP and TCP packets information and other connection status. UDP connections curve is in blue; TCP connection curve is in green; others curve is in red. Below of chart shows connections source and destination.

Chapter 6 Network



Basic

IPv4/IPv6 Settings

This page allows you to modify the device's IP settings.

IPv4 Settings		
IP Network Setting	DHCP = Static IP	
IP Address	192.198.1.1	
Subnet Mask	265 258 255 1	
Gateway	192 168 1 1	
Primary DNS	0000	
Secondary DNS	0000	
IPv6 Settings	# Link-local Address	
IP Address		
Subnet Prefix Langth		
Gateway		
Frimary DNS		
Secondary DNS		

IP Network Settings: Select whether the device IP address will use a static IP address specified in the IP address field or be obtained automatically when the device connects to a DHCP server.

IP Address: The IP address of this device.

Subnet Mask: The IP Subnet mask of this device.

Gateway: The Default Gateway of this device. Leave it blank if you are unsure of this setting.

Primary/Secondary DNS: The primary/secondary DNS address for this device.

Save: Click Save to confirm the changes.

Spanning Tree Protocol (STP) Settings

This page allows you to modify the Spanning Tree settings. Enabling the Spanning Tree protocol will prevent network loops in your LAN network.

Spanning Tree Protocol (STP) Settings

Enable * Disable	
2	seconds (1-10)
20	seconds (6-40)
15	seconds (4-30)
32758	(0-65535)
	Enable * Diseble 2 20 15 22708

Spanning Tree Status: Enables or Disables the Spanning Tree function. Default is Disable.

Hello Time: Specifies Bridge Hello Time in seconds. This value determines how often the device sends handshake packets to communicate information about the topology throughout the entire Bridged Local Area Network.

Max Age: Specifies Bridge Max Age in seconds. If another

bridge in the spanning tree does not send a hello packet for a long period of time, it is assumed to be inactive.

Forward Delay: Specifies Bridge Forward Delay in seconds. Forwarding delay time is the time spent in each of the Listening and Learning states before the Forwarding state is entered. This delay is provided so that when a new bridge comes onto a busy network, it analyzes data traffic before participating in the network.

Priority: Specifies the Priority Number. A smaller number has a greater priority than a larger number.

Save: Click Save to confirm the changes.

Chapter 7 2.4 GHz & 5 GHz Wireless



Wireless

Wireless Settings

Wireless Settings		
Device Name	ENS620EXT	
Country / Region	(antist)	

Device Name: Enter a name for the device. The name you type appears in SNMP management. This name is not the SSID and is not broadcast to other devices.

Band Steering (Avaiable on ENS620EXT): Enable Band Steering to send 802.11n clients to the 5 GHz band, where 802.11b/g clients cannot go, and leave 802.11b/g clients in 2.4GHz to operate at their slower rates. Before implementing this feature, we suggest you to assure the both 2.4GHz and 5GHz SSID, as well as security settings must be the same. EnGenius Band Steering supports following advanced settings,



*Force 5GHz: When band steering is configured to Force 5GHz mode, the AP will not dual band capable client

devices to network to the 2.4GHz band only if the client devices are not currently associated on 2.4GHz radio in this AP.



***Prefer 5GHz**: When band steering is configured to Prefer 5GHz mode, the AP will steer dual band capable client devices to 5GHz radio when the RSSI value of these client devices on 5GHz radio is more than set one. The allowed RSSI value for default setting is -75dBm.

Band Bakanoe +
SOHz RSSI -75 dBm Q
Percent of clients on SGHz radio 75 % 9
NOTE: In order for Band Steering function to work property, both 2.40Hz and 50Hz SSID and Security Settings must be the surver

***Band Balance**: When band steering is configured to Band Balance mode, the AP will steer dual band capable client devices to 5GHz when the RSSI value of these client devices on 5GHz radio is more than set one. To evenly allocate RF resource on the both 2.4GHz and 5GHz radios, users also can set the portion of client devices on 5GHz radio to assure smoothly connection. The default value of the 5GHz radio is 75%.

Save: Click Save to confirm the changes.

This page displays the current status of the Wireless settings of this AP.

2.4 GHz/5 GHz Wireless Network

	2.4GHz	SGHz
Operation Mode	Access Point 🔹 🕫 Green 😡	Actess Point · I Green Ø
Wreless Mode	BOZ 11 B/G/N ·	802-11 AC/N +
Channel H7 Mode	2058-02 +	40MHz +
Charnel	Configuration	
Transmit Power	And in case of the	-
Data Rater	AU10 +	And the second s
RTSICTS Threshold (1 - 2346)	2348	(International Action of the International Actional Action of the International Action
Client Limits	127 * Enable Disable	127 + Evatre - Disatte
Aggregation	32 Frames 00000 Eytes(Max)	
AP Detector	Dom	300
Distance (1-30km)	1 (0.6miles)	e (D fersion)

Operation Mode: Scrow down this list to select operation modes for implementing on this radio. The default operation mode is **Access Point** on base stations and Access Points and is **Client Bridge** on Client Premise Equipements (CPE). Meanwhile, EnGenius outdoor devices also support WDS modes for peer to peer or peer to multi-peer connections.

Wireless Mode: Scrow down this list to select wireless broadcasting standard on 2.4GHz and 5GHz frequency bands.

Channel HT Mode: Scrow down this list to select bandwidth for operating under a frequency band. The default channel bandwidth is 20 MHz on 2.4GHz frequency radio and 40 MHz on 5GHz frequency radio. Considering the different applications, users can decide to implement a channel bandwidth to fulfill real applications. The larger the channel, the greater the transmission quality and speed.

Transmit Power (Tx Power): Default Tx power is Auto to obey regulartory power of each country.

Channel: Click Configuration button to open a new windows to configure channels for performing wireless service.

2.4GHz		5GHz	
-	None	41	None
1,8,11	11,6,6,11	u-solet .	U-htt-2A
1,7	4,5,9	U-N11-20	D-ND-3
C1 91 . 2 #12 GHz	C> 02 1 7.417 GHz	CH 26 1 5 100 GPE	ch +0 - 5 200 GHz
C9 C1: 2.4G GHE	EN-04 :: 2 422 1042	13:44 - 5 275 GHz	09-45-5-240-685
D12512,432 GHz	Ct 00 : 2.477 GHE	01101 5 260 GHz	0+15:1,000 GHz
0107 2447 016	Ch (00) 2,447 GHz	09.60 \$,130.6897	- 0-14-5.320 GPb
1.5-129 主452.6Hz	GI-10.24570896	Chi90 : 5,508 6814	Ch104 5,524-0PU
Ch 11 - 7.462 GHz		CH100 1 1.547 GHz	0112 5.900 GPB
		CH132 1-640 (24z	LEAD & SHI GHT
		Dillay S745 GH2	0451 5765 689
		CHIST SCHESGHE	Od51 : 5.805 (24

And in case of the local division of the loc

***Default configuration**: Default setting of channel selection is **"All**" to perform auto channel on the exist channel list.

***None**: Click "None" to disable the setting on this radio. This radio is disabled.

***Group Configuration**: Click specific groups of channels for performing auto channel function. For example, users can click U-NII-1 and U-NII-3 to perform auto channel on these bands; the mechanism of this AP will select the relatively optimal channel to peform wireless service.

Data Rate: Select a data rate from the drop-down list. The data rate affects throughput of data in the AP. Select the best balance for you and your network but note that the lower the data rate, the lower the throughput, though transmission distance is also lowered.

RTS/CTS Threshold: Specifies the threshold package size for RTC/CTS. A small number causes RTS/CTS packets to be sent more often and consumes more bandwidth.

Client Limits: Limits the total number of clients on this radio. Once setting the ceiling of client numbers, the maximum assocaited client devices will be restricted at this number.

Aggregation: Integrate multiple data packets into one packet to deliver to client devices. This option reduces the number of packets, but also increases packet sizes.

AP Detection: AP Detection can select the best channel to use by scanning nearby areas for Access Points.

Distance: Specifies the distance between Access Points and client devices. The proper setting for this parameter may assist Access Points to avoid the improper operation when transmitting data under a filed application.

Save: Click **Save** to confirm the changes or **Cancel** to cancel and return to previous settings.

2.4 GHz/5 GHz SSID Profile

No	Enable	\$50	163		Security	Suppresent SSID	Station Separation	issisteri	VID
۴.	.90	EcGenius063C96;1-2.4GHz	Edit	None				.41	1
2	10	EnGenius053C96_2-2.40Hz	Edit	None		.35	10	.8.	2
3	11	EnGenus003C96_3.2.4GHz	Edit	None			10		2
٩.	11	EnGimile063036_4.2.4GHz	Edit	Norsa		1.10		11	4
5-	.5	ErGenus163026_5240Hz	Edit	None		100	12	0	8
6	2	EnGamun063036_6-2-40342	Edt	None		12	1 E.	0	6
7	10	Enclewas063C36_7.3 40Hz	Edit	None		100			1
8	10. I.	EnGenausDE3C96 8-2-46Hz	Edit	None					6

Wreless Settings - 5GHz

No.	Ender	SSID	Edit		leculty	Suppressed SSC	Station Separation	Holiston	. VID
Υ.	.00	EnGenus083G09_1-5GHz	EM	Nonia		- R.	30	-00	54
2	15	EnGranus063007 2-50Hz	Edit	Notei		e.,	· 10.	12	52
3	11	EnGenk/s063C97_3-5GHz	Edit	None		17	10	10	53
٠	11	EnGonus063G9/_4-5GHz	Edit	None		71	100	11	64
5	11	TeCenus063G97_5.8GH2	E:M.	Note			10	10	58
6	11	ChO#Not053C97_55GHz	Edit	None		12	11	12	50
1	10	EnGenue0000007_7.50Hz	Edt	None		10	101		śr.
8	10	EnGenational & Solle	EM	Nonix.		.81	100		58

Current Profile: You can configure up to sixteen (16) different SSIDs (eight (8) per band). If multiple client devices will be accessing the network, you can arrange the devices into SSID groups. Click **Edit** to configure the profile and check whether you want to enable extra SSID.

Enable: Click this check box to enable this SSID interface. The default SSIDs are enable on the both first 2.4GHz and 5GHz SSID.

SSID: Specifies the SSID for the current profile.

Hidden SSID: Check this option to hide the SSID from clients. If checked, the SSID will not appear in the site survey.

Client Isolation: Click the appropriate radio button to enable this function for allowing or preventing communication between client devices.

VID: Specifies the VLAN tag for each profile. If your netowrk includes VLANs, you can specify a VLAN ID for packets pass through the Access Point with a tag.

Wireless Security: See the Wireless Security section.

VLAN Isolation: Restrict clients communicating with different VIDs by selecting the radio button.

L2 Isolation: Enable this function prevenet client devices to communicate on the both WLAN and LAN.

Save: Click Save to accept the changes.

Wireless Security

The Wireless Security section lets you configure the AP's security modes

Wireless Security - 2.4GHz		
Security Mode	WEP	
Auth Type	Open System	
Input Type	Hex	
Key Length	40/64-bit (10 bex digits or	5.4.
Default Key	Key #1	•
Key #1		
Key #2		
Key #3		
Kary #4		

Secuirty Mode: Including WEP, WPA-PSK, WPA2-PSK, WPA-PSK Mixed, WPA, WPA2, and WPA Mixed. We strongly recommend you to use WPA2-PSK mode.

* Setting of WEP mode:

Auth Type: Select Open System or Shared Key.

Input Type:

ASCII: Regular Text (recommended) Hexadecimal Numbers (For advanced users)

Key Length: Select the desired option and ensure that wireless clients use the same setting. Your choices are 64, 128, and 152-bit password lengths.

Default Key: Select the Key you wish to be the default. Transmitted data is **ALWAYS** encrypted using the Default Key; the other Keys are for decryption only. You must enter a Key Value for the Default Key.

Encryption Key Number: Enter the Key Value or values you wish to use. Only the Key selected as Default is required. The others are optional.

Wireless Security - 5GHz		
Security Mode	WPA-PSK	•
Encryption	AES	
Passphrase		
Group Key Update Interval	3600	

* Setting of WPA-PSK, WPA2-PSK and WPA-PSK Mixed (Pre-Shared Key):

Encryption: You may select AES, TKIP or Both (TKIP+AES) to be the encryption type you would like. Please ensure that your wireless clients use the same settings.

Passphrase: Wireless clients must use the same Key to associate the device. If using ASCII format, the Key must be from 8 to 63 characters in length. If using HEX format, the Key must be 64 HEX characters in length.

Group Key Update Interval: Specifies how often, in seconds, the Group Key changes. The default value is 3600.

Wireless Security - 5GHz		
Security Mode	WPA-Enterprise	
Encryption	AES	•
Group Key Update Interval	3600	
Radius Server		
Radius Port	1812 Detaut 1812	
Radius Secret		
Radius Accounting	Disable	•
Radius Accounting Server		
Radius Accounting Port	eiti	
Radius Accounting Secret		
Interim Accounting Interval	\$160-	

* Setting of WPA-Enterprise & WPA2-Enterprise (Pre-Shared Key):

Encryption: Select the WPA encryption type you would like. Please ensure that your wireless clients use the same settings.

Radius Server: Enter the IP address of the Radius server.

Radius Port: Enter the port number used for connections to the Radius server.

Radius Secret: Enter the secret required to connect to the Radius server.

Radius Accounting: Enable or disable accounting feature.

Radius Accounting Server: Enter the IP address of the Radius accounting server.

Radius Accounting Port Enter the port number used for connections to the Radius accounting server.

Radius Accounting Secret: Enter the secret required to connect to the Radius accounting server.

Interim Accounting Interval: Specifies how often, in seconds, the accounting data sends.

Note: 802.11n does not allow WEP/WPA-PSK TKIP/ WPA2-PSK TKIP security mode. The connection mode will automatically change from 802.11n to 802.11g.

Wireless MAC Filtering

Wireless MAC Filtering is used to allow or deny network access to wireless clients (computers, tablet PCs, NAS, smartphones, etc.) according to their MAC addresses. You can manually add a MAC address to restrict permission to access this AP. The default setting is: **Disable Wireless MAC Filter**.

Note: Only applicable in Access Point and WDS AP modes.

Witniess MAC Filter		
AG, Mode	Childred	
	1000 1000 1	
No	MAC Address	

ACL Mode: Determines whether network access is granted or denied to clients whose MAC addresses appear in the MAC address table on this page. Your choices are: Disabled, Deny MAC in the list, or Allow MAC in the list.

MAC Address: Enter the MAC address of the wireless client.

Add: Click **Add** to add the MAC address to the MAC address table.

Delete: Delete the selected entries.

Save: Click Save to apply the changes.

Wireless Advanced

Save: Click Save to confirm the changes.

Wireless Traffic Shaping

Traffic shaping regulates the flow of packets leaving an interface to deliver improved Quality of Service.



Enable Traffic Shaping: Default is disable. You may check this option to enable Wireless Traffic Shaping per SSID.

Download Limit: Specifies the wireless transmission speed used for downloading.

Upload Limit: Specifies the wireless transmission speed used for uploading.

Per User: Check this option to enable wireless traffic shaping per user function. This function allow users to limit the maximum download / upload bandwidth for each client devices on this SSID.

Fast Roaming

Enable the function to serve mobile client devices that roam from Access Point to Access Point. Some applications running on Client devices require fast re-association when they roam to a different Access Point

Please enter the settings of the SSID and initialize the Security mode to WPA enterprise, as well as to set the Radius Server firstly. Users can enable the Fast Roaming and implement the advanced search.

Please also set the same enterprise Encryption under the same SSID on other Access Points and enable the Fast Roaming. When the configuration is realized on different Access Point, the mobile client devices can run the voice service and require seamless roaming to prevent delay in conversation from Access Point to Access Point.

Fast Roaming		
Enable Fast Roaming	Enable *	Disable

Enable Fast Roaming: Enable or disable fast roaming feature.

Enable Advanced Search: Enable or disable advanced search feature.

WDS Link Settings

Using the WDS (Wireless Distribution System) feature will allow a network administrator or installer to connect to Access Points wirelessly. Doing so will extend the wired infrastructure to locations where cabling is not possible or inefficient to implement.

Note: Compatibility between different brands and models of Access Points is not guaranteed. It is recommended that the WDS network be created using the same models for maximum compatibility.

Also note: All Access Points in the WDS network need to use the same Channel and Security settings.

To create a WDS network, please enter the MAC addresses of the Access Points that you want included in the WDS. There can be a maximum of four Access Points.

Note: Only applicable in WDS AP and WDS Bridge modes.

2.4 GHz/5 GHz WDS Link Settings

Mina frak antardit - 5 4	GH2	
Security	Notes -	
AE5 Painphrase	(1-63 ASCH characters or 04 hoxadocimal digits)	
10 1 2 4	MAC Address	tiote Deschier Deschier Deschier Deschier
WDS Link Settings - 5G+	iz	
WDS Link Settings - 5G+ Security	tz Norwjej	
WDS Link Settings +5G+ Security ALS Panaphrane	ez None	

Security: Select None or AES from the drop-down list.

AES Passphrase: Enter the Key Values you wish to use. Other Access Points must use the same Key to establish a WDS link.

MAC Address: Enter the Access Point's MAC address to where you want to extend the wireless area.

Mode: Select to disable or enable from the drop-down list.

Save: Click Save to confirm the changes.

Guest Network Settings

Adding a guest network allows visitors to use the Internet without giving out your office or company wireless security key. You can add a guest network to each wireless network in the 2.4 GHz b/g/n and 5 GHz ac/a/n frequencies.

Enable	\$300	. Tot		Security	Suppressed SSID	Station Separation
12	EnGenius-2.4GHz_GuestNet	fat	None		1.2	14
0	EnGenus-SOLU ClaristNetw	Fat	None		1.6	10
Masar	(P Softing)					
-PA	address		110 106 20	0.1		
-Sub	met Mask		100.200.20	0.6		
Automa	the DHCP Server Settings					
Sta	ting /P Address		120,108.20	35 100.		
End	ing IP Address		142.168-25	036.64		
-with	S Server IP		1000			

SSID: Specifies the SSID for the current profile.

Suppressed SSID: Check this option to hide the SSID from clients. If checked, the SSID will not appear in the site survey.

Station Separation: Click the appropriate radio button to allow or prevent communication between client devices.

IP Address: The IP Address of this device.

Subnet Mask: The IP Subnet mask of this device.

Starting IP Address: The first IP Address in the range of

the addresses by the DHCP server.

Ending IP Address: The last IP Address in the range of addresses assigned by the DHCP server.



RSSI Threshold: Enable the RSSI Threshold feature by ensuring that each client is served by at least one Access Point at any time. Access Points continuously monitor the connectivity quality of any client in their range and efficiently share this information with other Access Points in the vincinity of that client to coordinate which of them should serve the client best.

RSSI: Enter the RSSI (Received Signal Strength Index) in order to determine the handover procedure which the current wireless link will terminate. RSSI is an indication of the power level being received by the antenna. Therefore, the higher the RSSI number, the stronger the signal.

Chapter 8 Management



Management VLAN Settings

This page allows you to assign a VLAN tag to packets sent over the network. A VLAN is a group of computers on a network whose software has been configured so that they behave as if they were on a separate Local Area Network (LAN). Computers on VLAN do not have to be physically located next to one another on the LAN.

Note: Only applicable in Access Point and WDS AP modes.



Management VLAN: If your network includes VLANs, you can enable **Management VLAN ID** for packets passing through the Access Point with a tag.

Save: Click **Save** to confirm the changes or **Cancel** to cancel and return to previous settings.

Note: If you reconfigure the Management VLAN ID, you may lose your connection to this AP. Verify that the

DHCP server supports the reconfigured VLAN ID and then reconnect to this AP using the new IP address.

Advanced Settings

SNMP Settings

This page allows you to assign the Contact Details, Location, Community Name, and Trap Settings for a Simple Network Management Protocol (SNMP). SNMP is a networking management protocol used to monitor network attached devices. SNMP allows messages (called protocol data units) to be sent to various parts of the network. Upon receiving these messages, SNMP compatible devices (called agents) returns the data stored in their Management Information Bases.

SNMP Settings

Statue	In Enable - Draable	()
Contact		
Location		
Community Nerris (Real Only)	public	
Community Name (Read Write)	private	
Trap Destination		
Port'	162	
- IP Address		
- Community Name	public	
SNMPv3 Settings		
Status	* Energie Droatole	
Username	admin	(1-31 Characters)
- Authorized Protocel	MDS	
Authorized Key	12345678	(0-32 Characters)
- Private Pratocol	DE3	
Private Key	12345678	(8-32 Otiarecters)
Engine 10		

SNMP Enable/Disable: Enables or disables the SNMP feature.

Contact: Specifies the contact details of the device. **Location:** Specifies the location of the device.

Community Name (Read Only): Specifies the password for the SNMP community for read only access.

Community Name (Read/Write): Specifies the password for the SNMP community with read/write access.

Trap Destination Address: Specifies the IP address of the computer that will receive the SNMP traps.

Trap Destination Community Name: Specifies the password for the SNMP trap community.

SNMPv3: Enables or disables the SNMPv3 feature.

User Name: Specifies the username for SNMPv3.

Auth Protocol: Selects the authentication protocol type: MDS or SHA.

Auth Key: Specifies the authentication key.

Priv Protocol: Selects the privacy protocol type: DES.

Priv Key: Specifies the privacy key for privacy.

Engine ID: Specifies the engine ID for SNMPv3.

Apply Save: Click Apply Save to apply the changes.

CLI Settings

CLI Setting		
Shate	+ Eratin / Dualer	
SSH Setting@		
Salve	* Enable * Disable	
HTTPS Settings®		
(the second seco	* Enster 1 Diszter	
HITTPS forward	Environ + Devices	

CLI: The Command Line Interface (CLI) allows you to type commands instead of choosing them from a menu or selecting an icon.

SSH: Enable Secure Shell (SSH) to make secure, encrypted connections in the network. Secure Shell is a network protocol that allows data to be exchanged using a secure channel between two network devices.

HTTPS: Enable HTTPS to transfer and display web content securely. The Hypertext Transfer Protocol over SSL (Secure Socket Layer) is a TCP/IP protocol used by web servers to transfer and display web content securely.

Email Alert

You can use the Email Alert feature to send messages to the configured email address when particular system events occur.

Note: Do **NOT** use your personal email address as it can unnecessarily expose your personal email login credentials. Use a separate email account made for this feature instead

Email Alert			
Status	🗟 Enable		
+ From			
- To			
Subject	(Brood-AkingRNs	3620E x7280 C	
Email Account			
- Username			
- Password			
- SMTP Server		Port: 25	
- Security Mode	Noce	×	Sand Test Mas
Anton Anthe same interrupt to case all			

Status: Enable this function for further settings.

From: Enter the email address to show the sender of the email.

To: Enter the address to receive email alerts.

Subject: Enter the text to appear in the email subject line.

Username: Enter the username for the email account that will be used to send emails.

Password: Enter the password for the email account that will be used to send emails.

SMTP Server: Enter the IP address or hostname of the outgoing SMTP server.

Port: Enter the SMTP port number to use for outbound emails.

Time Zone

Time Setting

This page allows you to set the internal clock of the AP.

Date and Time Settings

Manually Se	et Date an	d Time
Date: 2016	/ 06	/ 16

Time: 07 (24-Hour) : 21

Synchronize with PC

Automatically Get Date and Time

NTP Server: pool.ntp.org

Time Zone

Time 2	Zone: UT	C+0	0:00	Ga	mbia, l	ibe	ria, Moro	0000	(ii)
Enat	ble Dayligh	t Sa	ving						
Start:	January		Tat		sun	+	00.00	+	
End:	January	i.	151	+	Mon	4	00:00	*	
Apply	Apply save	d set	ings t	o tai	ke effect				

Manually Set Date and Time: Manually specify the date and time.

Synchorize with PC: Click this button to synchorize Date and time of this AP with the PC.

Automatically Get Date and Time: Select

Automatically Get Date and Time and check whether you wish to enter the IP address of an NTP server or use the default NTP server to have the internal clock set automatically.

Time Zone: Choose a time zone to implement the service for this AP.

Enable Daylight Saving: Check whether daylight savings applies to your area.

Start: Select the day, month, and time when daylight savings time starts.

Enable Daylight Saving: Select the day, month, and time when daylight savings times ends.

Auto Reboot Settings

You can specify how often you wish to reboot the AP.



Auto Reboot Setting: Enables or disables the Auto Reboot function.

Timer: Select the day and enter the time you would like to reboot automatically.

Save: Click Save to apply the changes.

Wi-Fi Scheduler

The Wi-Fi Scheduler can be created for use in enforcing rules. For example, if you wish to restrict web access to Mon-Fri from 3pm to 8pm, you could create a schedule selecting Mon, Tue, Wed, Thu and Fri while entering a Start time of 3pm and End Time of 8pm to limit access to these times.

Wi-Fi Scheduler				
Status	Enable * D NOTE Please a enabling the V	sume assure that the Time 2 Ni-Fi Scheduler	one Settin	gt is synced with your local time when
Wireless Radio	10042			
SSID Selection	- Eriorentates	12.12.40+2.1		
Schedule Templates	Onune el temp	69 P		
	Day	Available		Duration
	Sunday	and a second	(9)	00 : 00 - 24 100
	Nonday		- 35	00 1 00 - 14 00
Schedule Table	Tuesday	and the second s	- 3	00 ± 00 = 24 ± 00
	Wednesday	openant.		$(20-00) \sim 74$ ($00)$
	Thursday	- and the second		21 05 = 24 :00
	friday	and the second s		00 : 00 + 24 (18)
	Seturday	The second s	1.0	00 - 00 - 24 1 (8)

Status: Enables or disables the Wi-Fi scheduler function.

Wireless Radio: Select 2.4 GHz or 5 GHz from the dropdown list for the preferred band type. **SSID Selection:** Select a SSID from the drop-down list.

Schedule Templates: Select a schedule template from the drop-down list.

Day(s): Place a checkmark in the boxes for the desired days or select the **All Week** radio button to select all seven days of the week.

Duration: The Start Time is entered in two fields. The first box is for hours and the second box is for minutes. The End Time is entered in the same format as the Start time.

Tools

Ping Test Parameters

This page allows you to analyze the connection quality of the AP and trace the routing table to a target in the network.

Ping Test Parameters			
Target IP / Dottain Name	1.1		
Ping Packet Size	64	Bytes	
Number of Pings	-4		
Start			
and the second sec			

Traceros	de Test Parameter	3		
Target P	/ Domain Name			
Start	300			
	modeling.			

Target IP: Enter the IP address you would like to search.

Ping Packet Size: Enter the packet size of each ping.

Number of Pings: Enter the number of times you wish to ping.

Start Ping: Click **Start Ping** to begin pinging the target device (via IP).

Traceroute Target: Enter the IP address or domain name you wish to trace.

Start Traceroute: Click **Start Traceroute** to begin the trace route operation.

Speed Test Parameters / LED Control

This page allows you to implement speed test to realize the throughput of a target DUT.

Speed Test Parameters

Target IP / Domain Name		
Time Period	20	Sec
Check Interval	5	Sec
IPv4Port	5001	
IPv6Port	5002	
Start		

Target IP / Domain Name: Enter an IP address or domain name you wish to impelement a speed test for realizing the variance on wireless speed.

Time Period: Enter the time in seconds that you would like the test to implement for and in how many intervals.

IPv4/IPv6 Port: This Access Points uses IPv4 5001 and IPv6 5002 port for the speed test.

Start: Click start to implement speed test.

LED Control

Control LED on/off for Power, LAN interface, or 2.4 GHz/5 GHz WLAN interface.

LED Control

Power		۲	Enable	Disable
LAN			Enable	Disable
WLAN-2.4	4GHz	٠	Enable	Disable
WLAN-5G	5Hz		Enable	Disable
Apply	Apply saved settings	to take effect		

Power: Enables or disables the Power LED indicator.

LAN: Enables or disables the LAN LED indicator.

WLAN-2.4 GHz: Enables or disables the WLAN-2.4 GHz LED indicator.

WLAN-5 GHz: Enables or disables the WLAN-5 GHz LED indicator.

Device Discovery

This page allows you to discover devices from network for Operation Mode, IP Address, System MAC Address and Firmware version.

Device Discovery						
Device Name	Operation Mode	IP Address	System MAC Address	Firmware Version		
Scan						

Account

This page allows you to change the AP username and password. By default, the username is: **admin** and the password is: **admin**. The password can contain from 0 to 12 alphanumeric characters and is case sensitive.

Account Settings

#
10
*

Administrator Username: Enter a new username for logging in to the New Name entry box.

Current Password: Enter the old password for logging in to the Old Password entry box.

New Password: Enter the new password for logging in to the New Password entry box.

Verify Password: Re-enter the new password in the Confirm Password entry box for confirmation.

Apply: Click Apply to apply the changes.

Firmware

Firmware Upgrade

This page allows you to upgrade the firmware of the AP.

Firmware Upgrade

Current Firmware Version: 1.0.0 Select the new firmware from your hard disk.

謝雪 Upload

To Perform the Firmware Upgrade:

- 1. Click the **Choose File** button and navigate the OS file system to the location of the upgrade file.
- **2.** Select the upgrade file. The name of the file will appear in the Upgrade File field.
- **3.** Click the **Upload** button to commence the firmware upgrade.

Note: The device is unavailable during the Firmware upgrade process and must restart when the upgrade is completed. Any connections to or through the device will be lost.

Backup/Restore

This page allows you to save the current device configurations. When you save your configurations, you also can reload the saved configurations into the device through the Restore Saved Settings from a file section. If extreme problems occur, or if you have set the AP incorrectly, you can use the **Reset** button in the Revert to Factory Default Settings section to restore all the configurations of the AP to the original default settings. **Backup Setting:** Click **Export** to save the current configured settings.

Restore New Setting: To restore settings that have been previously backed up, click **Browse**, select the file, and click **Restore**.

Restore to Default: Click **Reset** button to restore the AP to its factory default settings.

Backup/Restore Settings						
Factory Setting						
- Backup Setting	Export					
- Restore New Setting	選擇檔案	未選擇任何檔案	Import			
- Reset to Default	Reset					
User Setting						
- Back Up Setting as Default	Backup	1				
- Restore to User Default	Restore					
- Caution: Please write down you	r account num	ber and password bef	ore saving. The user settings will now			

become the new default settings at the next successful login.

User Setting

The function allows you to backup the current device configurations into the AP as the default value. If extreme problems occur, or if you have set the AP incorrectly, you can push the Reset button to revert all the configurations of the AP to the user default. **Back Up Setting as Default:** Click **Backup** to backup the user settings you would like to the device's memory for the default settings.

Restore to User Default: Click **Restore** to restore user settings to the factory standard settings.

Note1: After setting the current settings as the default, you should click the **Restore to Default** on the web interface for reverting the settings into the factory default instead of pushing the reset button.

Note2: Please **write down** your account and password before saving. The user settings will now become the new default settings at the next successful login.
Log

System Log

The AP automatically logs (records) events of possible interest in its internal memory. To view the logged information, click the **Log** link under the System Manager menu. If there is not enough internal memory to log all events, older events are deleted from the log. When powered down or rebooted, the log will be cleared.

\$138.4	· Enable 🖓 De	Late .
Log type	ALL	*
And summer	The Ad 12 12 30 The Ad 12 12 14 The Ad 12 12 14 The Ad 12 12 14 The Ad 12 12 12 The Ad 12 12 12 The Ad 12 12 12 The Ad 12 12 10 The Ad 12 12 04 The Ad 12 12 04 The Ad 12 12 04	Int 2016 open with property 1000, proved: USER and and POD pread where it dependent what risk of 2016 preen with convergence of SER Applied PO16 pread where it dependent what risk of 2016 preen with convergence of SER Applied PO16 pread where it dependent what risk of 2016 preen with convergence of the preed with the presence approximate where risk of 2016 preen with convergence of the preed with the presence of the preeming start risk of 2016 preen with convergence of the preed with the presence of the preed with the Applied preed with the preed with the preed with the presence of the preed with the Applied preed with the preed with the preed with the presence of the preed with the Applied preed with the preed with the preed with the presence of the the 2016 preed with the preed with the preed with the preed with the presence of the 2016 preed with the preed with the preed with the preed with the presence of the 2016 preed with the preed with the preed with the preed with the preed with the 2016 preed with the preed with the preed with the preed with the preed with the 2016 preed with the preed with the preed with the preed with the preed with the 2016 preed with the preed with the preed with the pree

Status: Enable/Disable this function.

ALL.	
Debug	100 million (1990)
Information	
Notice	
Warning	
Error	
Critical	
Alert	
Emergency	

Log type: You may choose one of log types to display logs in the following window. The default log types is All.

Remote Log	Enable Enable	
Log Server IP Address		

Remote Log

This page allows you to setup the Remote Log functions for this AP.

Remote Log: Enable/Disable this function.

Log Server IP Address: Enter the IP address of the log server.

Apply: Click Apply to apply the changes.

Logout

Logout: Click Logout in Management menu to logout.

ENSERGENT	Dual Radia Guidoor AF, 2728, 40095ps	- 867Hbga	Ouripei: 8	Renal	Logout
Destilien	Device Information				
Lancest Cathol CannetTaley Restmen Result Tomesta Result Tomesta Advancest Time Zone with Scheduler Toest Systematic Menager Advancest	Device Name MAC Adopted - UASL - UASL - Workess UAS - 2, AGAI - Workess UAS - 2, AGAI - Workess UAS - 36Mp Charley Charley Claretty Caretty Local Time Optima Frencese + Device. Management Wubb (2)	EVERAL220547 IIII: DC: 94:093-000-10 III: DC: 94:093-000-10 IIII: DC: 94:093-00-11 IIII: DC: 94:093-00-15 UCA Turi Sur 32:154:40-24 40:57/m;168 1.507 UPDisgent	2018		

Please confirm again to logout the system or not.



Reset

In some circumstances, it may be required to force the device to reboot. Click on **Reset** to reboot the AP.

ENSADDENT	Deal Radio Cuteour AP, 2128, 400Hbp	a = 007968ga	Charges 8	-	Legent .
OverView	Device Information				
Description Connections Realitions Notestime Notestime Notestime Notestime Advertices Three James Weif Tartestant Three James Weif Transform Three Second Account Notestime Note	Device Name Mic Adoress CANS CANS - Wreens LAN - 2.409m - Wreens LAN - 2.409m - Wreens LAN - 5640 Country Country Country Country Perman Adrian Perman Adrian	2006/09/07 10:00:09:00:00:1 10:00:09:00:00:1 10:00:00:00:1 10:00 10:00:00:10:1 10:00 10:00:00:10 10:00 10	0 1 2 1 0 2014		

Once you click reset button, you will see the options for reboot or restore this AP.

Reboot the device: Click it to reboot this device.

Restore to Factory Default: Click it to reset this device to factory default setting.

Restore to User Default: Click it to reset this device to user default settings. For realizing the setting method, vou may refer page 66 and page 67.

Reboot the device

Cauliforn Pressing this Sutton will cause the device to reboot. Report the device

Restore the device to default settings

Caultons All settings will be cleared and reset to intriar factory default or user default frestore to Factory Default Pestore to Law Denuit

Appendix



Appendix A - FCC Interference Statement

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help



FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IMPORTANT NOTE: Radiation Exposure Statement

ENS620EXT: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 21 cm between the radiator & your body.

ENS610EXT/ENS500-AC/ENS500EXT-AC: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 25 cm between the radiator & your body.

Appendix B - CE Interference Statement

Europe - EU Declaration of Conformity

This device complies with Directive 2014/53/EU issued by the Commission of the European Community.

- Declaration of Conformity

Please added certification standard in your user manual which depended on the test standards your device performed. or

- If the DoC should be a simplified version, please take below as reference -

Hereby, EnGenius Networks declares that the ENS500-AC/ENS500EXT-AC/ENS610EXT/ENS620EXT are in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

Devices	2412 - 2472 MHz	5180 - 5240 MHz	5260 - 5230 MHz	5500 - 5700 MHz
ENS500-AC	NA	NA	NA	CDD: 29.67 dBm; Beam.: 29.63 dBm
ENS500EXT-AC	NA	NA	NA	CDD: 28.77 dBm; Beam.: 28.77 dBm
ENS610EXT	CDD: 19.56 dBm; Beam.: 19.53 dBm	NA	NA	CDD: 25.33 dBm; Beam.: 24.91 dBm
ENS620EXT	CDD: 18.94 dBm; Beam.: 18.94 dBm	NA	NA	CDD: 29.98 dBm; Beam.: 29.98 dBm

The frequency and maximum transmitted power in EU are listed as belows,

Importer: EnGenius Networks Europe B.V.

Importer Address: ESP 240, 5633 AC Eindhoven, The Netherlands

Manufacturer : EnGenius Networks. Inc.

Manufacturer Address: No.500, Fusing 3rd Rd., Hwa-Ya Technology Park Kuei-Shan Dist., Taoyuan City, Taiwan (R.O.C.)

CE DoC Link: https://www.engeniusnetworks.eu/ens500ext-ac-ens500-ac-enstation5-accedoc

Appendix C - Industry Canada Statement

Industry Canada Statement (ENS500-AC/ENS500EXT-AC/ENS620EXT Only)

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.



Caution :

(i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

(ii) the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits specified for point-to-point and non-point-to-point operation as appropriate; and

(iii) Users should also be advised that high-power radars are allocated as primary users (i.e. priority users) of the bands 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.



Avertissement

(i) les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;

(ii) le gain maximal d'antenne permis (pour les dispositifs utilisant la bande de 5725 à 5850 MHz) doit être conforme à la limite de la p.i.r.e. spécifiée pour l'exploitation point à point et l'exploitation non point à point, selon le cas;

(iii) De plus, les utilisateurs devraient aussi être avisés que les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5650-5850 MHz et que ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.

Radiation Exposure Statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 25cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 25cm de distance entre la source de rayonnement et votre corps.

Appendix D - Professional Installation Instruction (FCC)

Installation Personal

This product is designed for specific application and needs to be installed by a qualified personal who has RF and related rule knowledge. The general user shall not attempt to install or change the setting.

Installation Location

The product shall be installed at a location where the radiating antenna can be kept 20cm from nearby person in normal operation condition to meet regulatory RF exposure requirement.

External Antenna

Use only the antennas which have been approved by the applicant. The non-approved antenna(s) may produce unwanted spurious or excessive RF transmitting power which may lead to the violation of FCC limit and is prohibited.

Installation Procedure

Please refer to user's manual for the detail.



Warning:

Please carefully select the installation position and make sure that the final output power does not exceed the limit set force in relevant rules. The violation of the rule could lead to serious federal penalty.

Appendix E - Professional installation instruction (IC)

Installation Personal

This product is designed for specific application and needs to be installed by a qualified personal who has RF and related rule knowledge. The general user shall not attempt to install or change the setting.

Installation Location

The product shall be installed at a location where the radiating antenna can be kept 26cm from nearby person in normal operation condition to meet regulatory RF exposure requirement.

External Antenna

Use only the antennas which have been approved by the applicant. The non-approved antenna(s) may produce unwanted spurious or excessive RF transmitting power which may lead to the violation of ISED limit and is prohibited.

Installation Procedure

Please refer to user's manual for the detail.



Please carefully select the installation position and make sure that the final output power does not exceed the limit set force in relevant rules. The violation of the rule could lead to serious federal penalty.

Appendix F - Instructions d'installation professionnelle (IC)

Installation Personal

Ce produit est destine a un usage specifique et doit etre installe par un personnel qualifie maitrisant les radiofrequences et les regles s'y rapportant. L'installation et les reglages ne doivent pas etre modifies par l'utilisateur final.

Emplacement d'installation

En usage normal, afin de respecter les exigences reglementaires concernant l'exposition aux radiofrequences, ce produit doit etre installe de facon a respecter une distance de 26cm entre l'antenne emettrice et les personnes.

Antenn externe

Utiliser uniiquement les antennes approuvees par le fabricant. L'utilisation d'autres antennes peut conduire a un niveau de rayonnement essentiel ou non essentiel depassant les niveaux limites definis par ISED, ce qui est interdit.

Procedure d'installation

Consulter le manuel d'utilisation.

Avertissement:

Choisir avec soin la position d'installation et s'assurer que la puissance de sortie ne depasse pas les limites en vigueur. La violation de cette regle peut conduire a de serieuses penalites federales.

Appendix G - DETACHABLE ANTENNA USAGE

Installation Personal

This radio transmitter (IC: 10103A-ENS500AC / Model: ENS500EXT-AC, ENS500-AC, EnStation5-AC, IC: 10103A-ENS620EXT) has been approved by ISED to operate with the antenna type listed below with maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio (IC: 10103A-ENS500AC / Model: ENS500EXT-AC, ENS500-AC, EnStation5-AC, IC: 10103A-ENS620EXT) a été approuvé par ISED pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

Approved antenna(s) list

Addet: ENS500-AC				
And Then	The	Commenter	Gam (dBi)	
wir.	type	Connecter	5.150 - 5.850GHz	
1	and a fail	HORAL .	13.35	
2	Patch	IPEX	13,42	

Model: Enstation5-AC					
And True	Promoted	(Gain (dBi)			
MAL	(Abe.	Connected	5.150 - 5 850GHz		
1	Prov.	- Cardo	15,3		
2	Patch	Patch IPEX	15.4		

Andel: ENS500EXT-AC					
Ant Type	Tuna	Commenter		Gain (dBi)	
	Ant Type Connecter 5,150	5,150GHz	5.550GHz	5.850GHz	
	Dipole	RSMA	5.12	5.09	5.17

Model: ENS620EXT

Ant. Type	Dipole		
Connecter Type	RSMA		
		Antenna Gain(dBi)	
2400%	/Hz	2450MHz	2500MHz
5.08		5.13	5.17
.5150M	1Hz	5550MHz	5850MHz
5,12	2	5.09	5.17
		and the second se	